CHARGE ‘N PLAY

USER’S GUIDE

www.dreamgear.net

Thank you for purchasing the Charge ‘n Play from dreamGEAR®

Package Contents:
- Charging dock
- AC adapter
- Rechargeable battery pack
- User’s Guide

Charging:
There are two methods for charging your Charge ‘n Plays rechargeable battery pack.

1. Charging only the battery.

2. Charging the battery from within the Wii™ Remote.

- Insert the rechargeable battery pack into the your Wii™ Remote battery compartment.

NOTE: up to 4 Charge ’n Play docks can be charged together. Attach each dock using the interlocking tabs. Connect each dock using the USB cable from one dock to another.

Charging using USB:

1. With the rechargeable battery inside the Wii™ Remote or by itself, place the battery or remote into the Charge ‘n Play dock and connect the USB cable to either of the 2 available USB ports on your Wii™ console. *(NOTE: Your Wii™ console must be powered on to charge the battery pack using USB.)*

Charging using AC adapter:

1. With the rechargeable battery inside the Wii™ Remote or by itself, place the battery or remote into the Charge ‘n Play dock. Connect the AC adapter to any wall outlet. Plug the USB plug from the dock into the AC adapter.

Charging Indicator: The Charging Dock features a LED that illuminates RED when charging and BLUE when fully charged.

NOTE: A complete charge takes 4-5 hours.

dreamGEAR
P.O. BOX 478
Torrance, CA 90508

FOR TECHNICAL SUPPORT
PLEASE CONTACT: 1-877-999-DREAM
or visit us on the web @ www.dreamgear.net

FOR TECHNICAL SUPPORT
PLEASE CONTACT: 1-877-999-DREAM
or visit us on the web @ www.dreamgear.net